



	1	ı		
DESIG	DESIGN DRAWN BY		DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHEC	KED AR	PROVED	DRAWING NO. D3416 sh	REV. A
DATE		l	TITLE	SCALE
05.03.14			MD500 (369) PEDAL LOCK	1:2
Α	05.03	3.14	NEW ISSUE	



### PEDAL LOCK SHOWN LOCKED WITH KEY




## D3416-051 PEDAL LOCK ASSEMBLY


## NOTES:

- 1) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED 2) ALL DIMENSIONS ARE IN INCHES

## COPYRIGHT © 2005 BY DART AEROSPACE LTD.








# **D3416-1 BASE**


### NOTES:


- 1) MATERIAL: 6061-T6/T651 (QQ-A-200/8 OR QQ-A-225/8) (REF. DART SPEC. M6061T6B) 2) COVER INSIDE HOLES PRIOR PAINTING 3) FINISH: CHEMICAL CONVERSION COAT PER DART QSI 005 4.1 POWDER COAT FIRE RED (4.3.5.10) PER DART QSI 005 4.3
- 4) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED 5) ALL DIMENSIONS ARE IN INCHES 6) BREAK ALL SHARP EDGES 0.005 TO 0.010

### COPYRIGHT © 2005 BY DART AEROSPACE LTD.









## D3416-3 COVER

### NOTES:

- 1) MATERIAL: 6061-T6/T651 (QQ-A-200/8 OR QQ-A-225/8) (REF. DART SPEC. M6061T6B)
- 2) COVER INSIDE HOLES PRIOR PAINTING
- 3) FINISH: CHEMICAL CONVERSION COAT PER DART QSI 005 4.1 POWDER COAT FIRE RED (4.3.5.10) PER DART QSI 005 4.3
- 4) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED
- 5) ALL DIMENSIONS ARE IN INCHES 6) BREAK ALL SHARP EDGES 0.005 TO 0.010